


Guide Book

- R/C controls forward/backward and left/right
- Music
- Volume adjustment and MP3
- Power display
- Forward and backward
- High and low speed
- Bluetooth
- USB
- TF card
- MP4(Optional)



Spare parts list


Name	A	B	C	D	E	F	G	H	I	J	K	L	M	N	O	P	Q	R
Car body	1	1	1	1	2	1	4	4	2	1	1	1	2	1	1	4	10	2



Product specification

Name	Specification
Battery	12V7A*1, 12V7A*2, 12V10A*1
Suitable age	3-7-95 months
Loading capacity	35kg
Product size	130*85*91cm
Speed	3-5 km/h
Charg/Use time	charge 8-10h, use 1-2h
Charger	Input: 220V-240V Output: 12V DC 1000mA (Input: 220V-240V Output: 24V DC 1000mA is optional)
Remote control	AAA1.5V

Function show




Button function

① Light	⑦ Music switch/Volume -
② Multifunction	⑧ Music switch/Volume +
③ High/low speed	⑨ Music
④ Forward	⑩ Power
⑤ Backward	⑪ Bluetooth
⑥ MP4	

Remote control function and explanation

- Do not swift forward/backward button when car is driving, or will damage the motor.
- Remote control can be used normally Speed when battery assembled.
- Remote control should be used under adults' supervision.
- Remote control is prior to man control.



How to adjust R/C frequency:
 Long press forward and backward Light indicator button for 3 seconds, and the speed indicator flashes. Then turn on the power, the speed indicator goes to long bright, means the connection successfully. If the speed indicator no response, means the connection failed. Replace the batteries and retry.

Remote control battery operation

- Take off the battery cover. Put two AAA1.5V remote control battery in with right polarity.
- New and used batteries can not be used mixed.
- Do not insert batteries into wrong polarity, or will be short-circuited.
- Non-rechargeable batteries can not be recharged. Exhausted batteries should be replaced by adults.
- The exhausted battery must be handled and operated properly by adults only. Do not be played by children.