## **WARNINGS:**

Not suitable for children under 5 years of age

Maximum capacity of 50kgs

Adult supervision required at all item

Children should be instructed on how to apply brakes before use

This product should not be operated on public roads, highways or bicycle paths

Read 'Safe operation' section before use

Always inspect and maintain product prior to use

## **SAFE OPERATION:**

This product must be assembled by an adult and checked by an adult before use

Ensure nuts and bolts remain securely fastened before use

Lubricate the chain often

Ensure the tires are pumped up before use – use hand pump only (maximum 30 PSI)

Perform a brake test before use

Do not store in direct sunlight

## **Material of products:**

A、 (PP) B、 (IRON) C、 (Pvc or Rubber)

# PLEASE READ THE INSTRUCTION CAREFULLY BEFORE USE

EN71-2:



#### **Execution Standard**

EN71-1: 2014 for Mechanical And Physical Properties

2011+A1: 2014 Flammability Test

EN71-3:2013+A1:2014 for migration of certain elements Please read this manual carefully before use

Caution: For correct and safe operation of this product, be sure to read this instruction manual carefully before use. Please retain this user manual for future reference.

## Page2





1.one frame

2.one front panel







4.one steering wheel

### Page7

7. Place the steering wheel cover in the center of the steering wheel.



8. Fix the seat to the frame of the go-kart using 5\*45mm bolts, ensure to use washers again where appropriate.



### Page4

# **Assembly Instructions:**

1.Attach the steering support to the frame of the go-kart. Fix with M5\*50mm bolts and ensure to use washers where appropriate.



2.put the front panel to the frame



#### Page5

3. Use the 4\*10 bolts to fix the front panel to the frame



4.Please put one square washers in the both sides of the steering wheel as the photo




#### Page6

5.Insert the steering shaft through the turning pole. Place the front panel over the steering shaft.



6. Fix the steering wheel as the photo, the parts are in tur: one square washer, one Spring gasket, one M8 nut



Page3



5.one steering shaft (1xM8 nut 1xM8 Spring gasket 1xplastic gasket 2xsquare washers 1xM10 iron gasket)



6.Bag of nuts and bolts (4 x M5\*50mm bolts, 4 x M5\*45mm bolts, 2x4\*10mm bolts, 8xM5 nuts, 8xM5 gaskets)



7.Steering Wheel Cover



8. One steering support

9.one specification