

The instruction manual contains important information. Please keep it properly.

Age of application: 3-8 year

INSTRUCTION MANUAL

Children's electric car

USE NOTE

1. Before use guardians must read the instructions carefully.
2. The applicable age is for children over 3 years old.
3. The maximum load of the product are 30kg, no overload.
4. The product needs to be assembled by adults.
5. Do not upside down the battery, do not change the connections.
6. Before to recharge, please check if any damage is found to recharge should be stopped until the repair. Recharge should be conducted by adult and supervise children not to approach.
7. Battery heating during charging is normal, when the temperature is too high should be stopped.
8. The battery must be fixed with a plate. If the car turns over, the battery may cause injury to the child.
9. If not used for a long time, it must be recharging fully.
10. The power must be turned off when charging.
11. Before charging put the charger on the DC plug and then connected to the power outlet.
12. Charger and battery is not toy, children are not allowed to play.
13. The charging time takes 8-12 hours.
14. When the running speed is slowed obviously, the battery power is low and need to be to recharge, please charge it in time.
15. Do not use in water, do not pour water and other liquid into product, may cause short circuit.
16. The remote controller battery uses AAA*2 batteries.
17. If remote controller operation is out of control, it may be the battery power is insufficient, please replace the battery in time to avoid dangerous.
18. The heating phenomenon (under 60°C) of the charger and battery occurs to charging, which is normal.
19. Batteries that can no longer be used should be removed from the product in time and handled properly so as not to cause environmental pollution.
20. The toy cannot be connected to the power supplies whose quantity are more than the recommended quantity.
21. Remove and insert the remote control batteries, unscrew the back screws of the remote controller, open the cap, and remove the battery, install batteries according to polarity indicated on the remote control then lock the screws.
22. To remove and insert the main battery in the car body, the red wire connect to the red terminal on the battery, the same the black wire connect to the black terminal.
23. The battery must be placed in correct terminal (positive and negative), and the terminals must not be short circuit.

WARNING

1. The instructions contain important information, please keep them carefully for later use.
2. Keep plastic bags away from children.
3. Contain small parts, not suitable for children under 3 years of age.
4. May contain sharp edges before assembly, need to be assembled by adults and keep children away.
5. Use under adult guardianship.
6. To avoid be used in dangerous areas such as the road, slope or street.
7. Please drive in flat ground, to avoid be used in smooth ground such as marble, floor tile.
8. Before using the adult must account to the child the right operation method, and use under supervision of adults.
9. Must be under guidance of adults to use, adults do not be allowed to leave.
10. All batteries shall be installed in the correct polarity.
11. Do not mix different types batteries or mix new and old batteries.
12. Each part such as transformers, DC adaptor or battery chargers etc. used with the toy must to be regularly examined for damage to the cord, plug, enclosure and other parts, and in the event of such damage, product must not be used until the damage has been repaired.
13. Do not be near fire and water.
14. Do not exposure to the sunshine and rain.
15. Exhausted batteries should be taken out of the product and remote controller.
16. Non-rechargeable batteries cannot be charged.
17. Product should be stored away from fire and heat sources.
18. Should be placed flat and should not be reversed or tilted.
19. Do not use when rain and snow drive outside, the water may damage the motor, wire system and battery.
20. When charging, keep away from inflammable and explosive materials to prevent fire.
21. The power supply terminals should not be direct short.

Manual control: the driver sits well, presses the power switch, activate the sound. Put the switch on the forward, stop, back, switch "forward", step on the pedal switch, the car forward, release the pedal, the car stopped. The switch is "back" and step on the pedal switch, the car reverse, loosens the pedal, and the car stops. "stop" car cannot run. The steering wheel controls the left and right direction. Remote control: before use need to make a pair the car and remote controller. 1. Turn off the car 2. Press the [M] button until the remote controller light flashes, then turn on the car immediately, remote controller and car make a pair successful. The remote controller can control the car now. Can not use rechargeable batteries for remote controller.

MAINTENANCE

1. After each use, it must be charged in time, and the normal charging time is 8-12 hours.
2. When the speed is slower than usual, it should be charged in time.
3. Under the condition of long-term non-use, the car should be charged once every month to avoid excessive discharge and affect battery life.
4. When the voltage is too low, it needs to be charged.
5. Use a small amount of lubricating oil to lubricate the parts of the rotating parts of the product for a period of time to prevent wear and rust.
6. The product should be placed indoors or covered with waterproof cloth.
7. After use, please charge timely, if long time do not use, it must be maintaining a sufficient of power, and once a month charge.
8. With dry soft cloth wiping product and parts, do not use chemical solvents to wipe the part; do not clean vehicles with water.
9. When stop using or placing the product, cut off the power of the product and switch all the switches to "stop" or "off" position.
10. Do not use fuse that is not in conformity with this product specification.
11. Do not change the product structure and part, maintenance work must be professionals or under professionals guide.
12. Charge at least once a month if do not use it for a long time.



LEAN CARS

Body	Handle	Frame						
Seat	Wheel	Cap	Charger					
Part	Body	Handle	Frame	Seat	Cap	Wheel	Charger	
Q'ty	1	1	1	1	4	4	1	

